User manual

Istarera　Smart MP3 Bluetooth Handset

Declaration

1、 All rights reserved. No part of this publication may be reproduced , redistributed, resold or loaded without the prior written consent of Istarera Limited.

2、 Data contained in Istarera Limited's databases has been complied by Istarera in good faith from sources believed to be reliable, but no representation or warranty express or implied is made as to its accuracy, completeness or correctness.

3、 Information contained herein is subject to change without notice.

4、 Neither Istarera nor such other part who may be the owner of the Proprietary Information accepts any liability whatsoever for any direct, indirect or consequential loss arising from any use of such Proprietary Information.

Cautions

Guideline for safe and efficient use, please read this information before using your handset. These instructions are intended for your safety, please follow these guidelines.

1、 Do not drop, throw or strike your handset.

2、 Do not make your handset close to benzene， thinner and other chemical materials.
3、Do not make your handset close to magnetic material.
4、Do not expose your handset to extreme sunshine and high humidity.
5、Do not attempt to disassemble or modify your handset.
6、Do select right volume, if you feel a drumming in the ears, please adjust low volume or stop using it.
7、Do not dispose the package, battery and waste electronic equipment.

Introduction

This is a multi-functional stereo Bluetooth handset, you can use it to:
●Making calls with Bluetooth
●MP3 player
●FM radio

Graphic

1、 NEXT next
2、 ENTER/PLAY/PAUSE play/pause
3、 PREVIOUS previous
4、 BACK/MENU start/close the menu, back
5、 Micro USB Cable Charger Plug in the charger /USB data cable for charge or transmit the file
6、 Micro SDTM card port
7、 Attaching Clamp
8、 OLED Display
9、Action Key click to answer, press long to reject, hold down 3mins to redial
10、 Power Hold down the button for about 3 seconds to turn on/off the headphone
11、Earphone Jack (3.5mm minijack)
12、Microphone
13、Volume Turner Control the volume
14、Earphone Receive\make calls
15、String

Basic Information

Charging for your handset

Your handset has been given an initial charge up to 2.5 hours to get going.
1.To insert the charger into the power socket.
2.Plug the supplied USB cable into the charger(or into a spare USB socket on your computer)
3.Plug the other end of the USB cable into your smart Bluetooth handset.

Switch on and off the handset

1.With the handset switched on until it shows “WELCOME” on the OLED screen, it turns on.
2.With the handset switched on until it shows “BYEBYE” on the OLED screen, it turns off.

MENU

Select the menu mode, press Pre/Next to overview the menu.
1.FM radio
2.Play music in Micro SDTM card, or in paired device
3.REC MODE
4.Press ENTER to confirm, or back.

Bluetooth pairing

To use the handset, you need to pair it with your phone. Pairing creates a stored link between the phone and the handset. Once paired, they will reconnect automatically in future.
With the handset switched on, pairing procedure is below.
1.Press the menu key
2.Press the before/after key, select the menu and press Enter key
3.Press the before/after key, select Bluetooth and press Enter key
4.Press the before/after key, select Pairing Bluetooth and press Enter key

Select the music source

Before you play the music, please select the music source. Your handset can play music as below:
1.FM radio
2.Micro SDTM card in the handset
3.Paired Bluetooth device.

Phone book synchronization (read out the names or numbers)

With the handset Bluetooth connected, press into the Bluetooth setting, select phonebook synchronization and press ENTER key. (No limit on the amount of your phonebook)

Making calls

1、Click the button once to answer the call.
2、Press the button to reject the call.
3、Hold down the button for about 3 seconds to redial the last call.
4、Remove the headphone, you can also make calls directly.

Voice recording

With MeGoo calls in the process, click play <pause key > , start the recording, the upper left corner in the recording chart;Click again to play <pause key > , stop the recording, the upper left corner graphic recording disappear.

The meeting recording

Under the previous menu select <recording > icon, click < play pause > enter the recording secondary menu;Choose < recording mode > icon, click < play pause > enter the recording, the screen shows "please record";Click < play pause > start recording, the screen shows "recording";In the process of recording click play <pause key> , can pause the recording, the screen shows "pause" recording;Suspended state, click again to play < pause key> , can restore the recording, the screen shows "recording";The recording is completed, press < return > to save the recording, the screen shows "saved".

Play the recording file

In the recording secondary menu, select <play mode > icon, click < play pause > into recording playback mode;Choose to play audio, click < play pause > can play this file.

Microphone usage

It can be used as a microphone when you making calls, not suitable for MP3 player or FM radio.

MP3

To select music mode in the menu, press ENTER key to go into Micro SDTM.

FM radio

To select FM radio mode, press ENTER key to listen to the radio, press ACTION key to search automatically.

Transmitting the music file

1、Connect the handset and computer via the data cable.
2、The smart Bluetooth handset can be used as a storage device.
3、The storage of the handset depends on the Micro SDTM card.
4、Maximum storage : 32G

Troubleshooting

●Cannot connect with your phone.

Be sure your handset is full charge and switched on, the suggesting maximum distance between the handset and phone is 10 meters and without any blocked. To check the connection from your phone, reconnect them when necessary.

●Cannot play music from your phone.

Be sure your handset and your phone are connected, reconnect them when necessary
Be sure you select the voice source.

●The handset keeps Switching Itself Off.

This is likely to be because the handset's battery is running low. If the battery gets very low, it automatically turns itself off. You should charge your handset using the supplied USB cable and adapter.
●Unexpected situation
Reset the device
If you are having an unexpected situation with your handset, the first thing to try is to reset the device, and start again: see"Restting " for more information.